


GLOW PLUG, WIRES, FUEL SUPPLY, NOZZLE AND HOLDER




Ref. No.	Part No.	Description	No. Req'd	Ref. No.	Part No.	Description	No. Req'd
1	888928	Holder & nozzle, complete	3	9	834656	Plug, glow	3
2	834661	Gasket	3	10	834492	Wire, glow plug	2
3	834479	Pipe, injection, (1)	1	11	888927	Pipe, fuel overflow, complete	2
4	834480	Pipe, injection, (2)	1	12	834315	*Clip, pipe	1
5	834540	Pipe, injection, (3)	1	13	834475	*Pipe, fuel overflow	1
6	834343	Clamp, pipe, (1)	2	14	888948	Pipe, jet start, complete,	1
7	834344	Clamp, pipe, (2)	2	15	◇◇	*Pipe	1
8	834281	Screw w/washer head, M5 x .8 x 20, pan head	2	16	834315	*Clip, pipe	2

◇◇ Not Offered


* INDENTED PART NAMES INDICATE THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY.

SPEED CONTROL LEVER AND PLATE



Ref. No.	Part No.	Description	No. Req'd	Ref. No.	Part No.	Description	No. Req'd
1	834574	Bolt, adjusting	1	11	834489	Plate, friction	1
2	834633	Nut	1	12	834578	Plate, speed control	1
3	834649	Gasket	2	13	834488	Gasket	1
4	834647	Nut, cap	1	14	834252	Bolt, M6 x 1 x 20	3
5	834648	Cap	1	15	834385	Stud	1
6	834611	Lever, speed control	1	16	834276	Nut, flange, M6 x 1 x 5 6T	3
7	834515	Key, feather	1	17	834287	Lockwasher, M6	1
8	834294	'O' ring, JIS P7	1	18	834341	Stopper	2
9	834283	Washer, plain, M6	1	19	834662	Bolt	1
10	834274	Nut, lock, M6 x 1 x 3.6 4T	2				

GOVERNOR CONTROL LEVERS




Ref. No.	Part No.	Description	No. Req'd	Ref. No.	Part No.	Description	No. Req'd
1	834361	Spring, start	1	11	◇◇	••Screw, adjusting	1
2	834558	Spring, governor lever (1)	1	12	834576	•Lever, fork (2)	1
3	888952	Lever, governor (1)	1	13	834486	•Shaft, fork lever	1
4	888953	Lever, fork, complete	1	14	834260	•Bolt, M5 x .8 x 16 7T	1
5	888981	• Lever, fork	1	15	834286	•Lockwasher, M5	2
6	◇◇	••Lever	1	16	834487	•Holder, fork lever	1
7	◇◇	••Button, stop	2	17	834493	•Bolt	1
8	◇◇	••Button, adjusting	1	18	834254	Bolt, M6 x 1 x 28	2
9	◇◇	••Spring, adjusting	1	19	834577	Spring, governor (2)	1
10	◇◇	••Button	1				

◇◇ Not Offered


• INDENTED PART NAMES INDICATE THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY.

THERMOSTAT, HOSES, COVER, FLANGE



Ref. No.	Part No.	Description	No. Req'd	Ref. No.	Part No.	Description	No. Req'd
1	834680	Flange, cooling (water)	1	11	834623	Gasket	1
2	834495	Gasket	1	12	834255	Bolt, M6 x 1 x 35	2
3	834250	Bolt, M6 x 1 x 16	5	13	834553	Pipe (2)	1
4	834270	Stud, M6 x 1 x 55 7T	1	14	834621	Hose, water return (3)	1
5	834276	Nut, flange M6 x 1 x 5 6T	1	15	834494	Clamp	2
6	834287	Lockwasher, M6	1	16	834688	Plug	1
7	834624	Pipe, water return (1)	1	17	834589	Gasket	1
8	834679	Hose, water return (2)	1	18	834681	Plug	1
9	834625	Clamp	2	19	834622	Cover, thermostat	1
10	888964	Thermostat	1				

FUEL CAMSHAFT, GEAR, INJECTION PUMP



Ref. No.	Part No.	Description	No. Req'd	Ref. No.	Part No.	Description	No. Req'd
1◇	888949	Pump, injection, complete	1	15	834485	•Cir-clip, governor case	1
2	834265	Bolt, M8 x 1.25 x 22 7T	2	16	834309	•Ball, M, 17/32" (13.49mm)	8
3	834386	Stud	2	17	834290	•Cir-clip,external, M18	1
4	834278	Nut, M8 x 1.25 x 6.5 6T	2	18	834310	Bearing, ball	1
5	834288	Lockwasher, M8	2	19	834291	Cir-clip, external, M20	1
6	888940	Camshaft, fuel, complete	1	20	834461	Stopper, fuel camshaft	1
7	834534	•Camshaft, fuel	1	21	834248	Bolt, M6 x 1 x 12	4
8	834313	•Bearing, ball	1	22	834430	Gasket	1
9	834478	•Gear, injection pump	1	23	834316	Joint	1
10	834305	•Key, feather, M5 x 20	1	24	888942	Shims, injection pump	1
11	834482	•Sleeve, governor	1	25	834519	.Shim, injection pump	2
12	834483	•Cir-clip, governor sleeve	1	26	834539	.Shim, injection pump	3
13	834484	•Case, governor ball	1	27	834431	Cover	1
14	833899	•Ball, M, 5/32" (3.97mm)	30	28	888914	Cock, jet start, complete	1

◇ Refer to page 24 for replacement parts.

• INDENTED PART NAMES INDICATE THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY.